

It is now easier than ever to match mouldings, trims, decorative accent pieces, and more to our framed painted styles with our new custom matched Finish Repair® Spray Paint\*.

\*This custom matched spray paint from Finish Repair<sup>®</sup> is only available for purchase through CabinetCorp and its authorized resellers. Color variations are possible with improper use in which case claims are not permissible. <u>\*Improper use includes but is not limited to, respraying of CabinetCorp products, spraying too close to the items' surface, and improper surface preparation prior to spraying.</u>

## Availability & Suggested Uses



### Finishes Available

• White

• Antique White

• Dusk

• Gray

These spray paints are classified as a basecoat with a mid-satin finish.

# MouldingsTrims

Suggested Uses\*

- 111115
- Decorative Accents
- Small Touch-Ups

\*This product is recommended for indoor use and for use on wood products. We cannot guarantee outcome for use on other types of materials.

## **Preparation & Directions**

1.Prep the Surface

• Ensure the surface is sanded, clean of debris, dry, and free from any holes, cracks, and/or surface scratches.

• Use primer on raw/unfinished wood.

2.Spray outdoors or in well ventilated area when temperatures is between 68° and 78°F and humidity is below 60% to ensure proper drying.

- Mask surrounding area where over spraying might settle.
- 3.Take Protective Measures

• Use goggles, wear a mask, cover your head with a shower cap (or similar), utilize gloves, etc.

4.Shake can for at least 1-minute, listening for rattle of mixing ball prior to initial use.

• Shake for 10-seconds at 1-2 minute intervals during application.

5.Hold can 6 to 10 inches from surface to prevent overspraying.

• Press spray button firmly during use.

• Do not cover with continuous spray. Move back and forth releasing the spray head after each stroke. Overlap each stroke.

6.Provide Enough Time for Drying In-Between Multiple Coats (Approx. 25-30 minutes)

• For best results, apply two thin coats, rather than one heavy coat.

#### See spray can for additional information.